

SPEC SHEET + MEASUREMENTS

Eddie Bauer

Eddie Bauer® Packable Wind Jacket. EB500

Product photo




Wind was the inspiration for this compact layer. Plus, it packs down into its own logo-adorned pocket, making it easy to carry wherever you go.

- 100% nylon
- Hood with locking drawcords for adjustability
- Contrast reverse coil zipper
- Underarm vents
- Packs into its own zippered chest pocket
- Front unzipped pockets
- Elastic cuffs and an open hem
- Contrast Eddie Bauer logo on right chest

CARE INSTRUCTIONS

Secure all garment before laundering Machine wash warm delicate separately Use mild detergent rinse throughly Do not bleach Tumble dry low or for best result line dry Do not iron. Do not dry clean

Sketches



front



back

PRODUCT MEASUREMENTS

	XS	S	M	L	XL	2XL	3XL	4XL
Body Length at Back	28	28 1/2	29	29 1/2	30 1/2	31 1/2	32	32 1/2
Chest	21 1/2	23	24 1/2	26	27 1/2	29	31	33
Sleeve Length	34 3/4	35 1/2	36 1/4	37	37 3/4	38 1/2	39 1/4	40

Body Length at Back: Measured from high point shoulder to finished hem at back.


Chest: Measured across the chest one inch below armhole when laid flat.

Sleeve Length: Start at center of neck and measure down shoulder, down sleeve to hem.

SIZE CHARTS

	XS	S	M	L	XL	2XL	3XL	4XL
Chest	32-34	35-37	38-40	41-43	44-46	48-50	52-54	55-57

HOW TO MEASURE



CHEST
Measure under the arm and around the fullest part of the chest with arms down, keeping tape horizontal.

COLORS

Please note: PMS code information is shown only when an exact match is available.



Adriatic Blue
PMS 4161C



Black
PMS BLACK C



Grey Steel
PMS 7540C